

INSTALLATION INSTRUCTIONS



Energy Manager PRO 6000C

Keep these instructions with the boiler at all times.

BOYERTOWN FURNACE Co.

PO Box 100

BOYERTOWN, PA 19512

1-610-369-1450

www.boyertownfurnace.com

Be Aware of Hazard Definitions

| | |
|----------------|--|
| Danger | Denotes presence of a hazard which, if ignored, will result in severe personal injury, death or property damage |
| Warning | Denotes presence of a hazard which, if ignored could result in severe personal injury, death or substantial property damage. |
| Caution | Denotes the presence of a hazard, which if ignored, could result in minor personal injury or property damage |
| Notice | Intended to bring attention to information, but not related to personal injury or property damage. |

Danger

This equipment must be installed, adjusted, serviced and started only by a qualified service agency – an individual or agency, licensed and experienced with all codes and ordinances, and who is responsible for the installation and adjustment of the equipment. The installation must comply with all local codes and ordinances and with the latest revision of the National Fire Protection Standard for Oil Burning Equipment, NFPA 31.

Read all instructions before proceeding. Follow all instructions completely. Failure to follow these instructions could result in equipment malfunction causing severe personal injury, death or substantial property damage.

Do not alter this kit or the boiler in any way. The manufacturer will not be liable for any damage resulting from changes made in the field to the boiler or its components or from improper installation. Failure to comply could result in severe personal injury, death, or substantial property damage.

Your oil fired boiler is designed to burn No. 1 and No. 2 heating oil only. Never use gasoline or a mixture of gasoline and oil.

Do not store gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance. The area around the boiler should be kept free and clear of combustible materials.

Never burn garbage or refuse in your boiler.

Never try to ignite oil by tossing burning papers or other material into your boiler.

Do not attempt to start the burner when excess oil has accumulated or the boiler is full of vapors.

Do not operate boiler if the heat exchanger is damaged.

Do not jumper, attempt to bypass or override any of the safety limit controls.

Do not use this boiler if any part has been under water. Immediately call a qualified service technician to inspect the boiler and replace any part of the boiler, control system or burner that has been under water.

All installations must conform to the requirements of the authority having jurisdiction. Such applicable requirements take precedence over the general instructions of this manual.

Where required by the authority having jurisdiction, the installation must conform to the American Society of Mechanical Engineers Safety Code for Controls and Safety Devices for Automatically Fired Boilers, ANSI/ASME CSD-1.

Notice

Concealed Damage- If you discover damage to the burner, boiler or controls during unpacking, notify the carrier at once and file the appropriate claim. When calling or writing about the boiler please have the following information available: The boiler model number and serial number.

Table of Contents

| | |
|---|----|
| Specifications..... | 4 |
| Energy Manager Pro 6000C Features..... | 4 |
| Installing the Energy Manager Pro 6000C..... | 4 |
| Internal Components..... | 6 |
| HydroStat Bezel | 7 |
| Caleffi Zone Board..... | 7 |
| Caleffi Settings and Connections..... | 8 |
| Electrical Wiring..... | 10 |
| Internal Wiring..... | 11 |
| Field Connections Circulators with Plug n' Go Plus..... | 12 |
| Field Connections Circulators with Customer Supplied Indirect Circulator..... | 13 |
| Optional Indirect Water Heaters..... | 14 |
| System Check Out..... | 14 |
| Control Circuit Safety Checks | 14 |
| Installation and Service Check List..... | 15 |
| Warranty..... | 16 |
| Warranty Registration | 20 |

Specifications

| | |
|-------------------------------|----------------|
| Input Voltage: | 120VAC |
| Maximum Burner Amps: | 5.8 FLA |
| Maximum Individual Pump Amps: | 5 Amps @120VAC |
| Maximum Total Zone Amps: | 20Amps @120VAC |

Energy Manager Pro 6000C Features

The Energy Manager Pro 6000C integrates a Caleffi ZSR106 control along with a Hydrolevel Fuel Smart 3250 HydroStat to provide superior energy savings, enhanced zone control, and plug and play technologies for easy installation. Indicator lights show individual zone calls for heat, allowing for easy diagnostics. Also included is a transformer for the sole purpose of serving as an individual 24VAC supply for ancillary equipment.

The ZSR106 is a versatile control relay capable of operating up to 6 zones of heating. Zone 1 can be enabled for priority and/or post purge via dip switch. This is ideal for wiring up an indirect water heater, ultimately giving Domestic Hot Water plus 5 zones of heat. This relay control is compatible with 2, 3, and 4 wire thermostats. Refer to Caleffi literature for a complete description of features.

The Hydrolevel Fuel Smart HydroStat 3250 control combines the functions of low water cutoff with Thermal Targeting technology. Thermal Targeting technology analyzes thermostat activity and continually evaluates how much heat the house requires. When the heat demand is high, the Fuel Smart HydroStat will raise the boiler's target temperature to provide the needed heat to the home. When the heat demand is low, the HydroStat will lower the boiler's operating temperature to save fuel while continuing to provide comfort to the home. Refer to the provided Hydrolevel literature for a complete description of features.

Remote Mounting The Energy Manager Pro 6000C


The Energy Manager Pro 6000C can be mounted remotely to operate any boiler.

1. Using the keyhole slots in the base, the Energy Manager Pro 6000C may be mounted to hang from an existing boiler or wall. The fasteners required to mount the control on a wall must be able to support the pound weight load of the control
2. Install the proper Hydrolevel Electro-Well into the boiler for proper operation of the low water cut off features of the control.
3. Install the Hydrolevel sensor into the Electro-Well following the instructions supplied with the sensor kit. Remote sensor kits are available in lengths up to 20 feet.


Installing The Energy Manager Pro 6000C To A Trio Boiler

1. Lift and remove the jacket front panel.
2. Remove the two 7/8" knockouts in the jacket top panel. Note these are double tabbed knockouts which must be removed by bending opposite the tabs.
3. Install the supplied box connectors into the 7/8" holes in the front of the Energy Manager Pro 6000C.
4. Insert the box connectors through the 7/8" hole in the jacket top panel. Thread on the lock nuts to the box connectors and tighten.
5. Anchor the rear right-hand corner of the box to the jacket through the keyhole slot using a self drilling screw.
6. Remove the HydroStat 3250 from the burner box and return as it is not required.


7. Remove the Hydrolevel sensor wire and ground wire which is running through the side of the jacket, rerouting it through the box connector of the Energy Manager Pro 6000C. Plug the sensor wire into the HydroStat and attach the ground wire to a grounding screw.



Internal Components




HydroStat Bezel Indicating Lights




1. Temp Active – HydroStat is powered and temperature function is active
2. Temp High – Illuminated when the boiler reaches the high limit temperature
3. LWCO Active – Indicates the low water cut off is active
4. Low Water – Indicates that the boiler is shut off due to a low water condition
5. Economy Active – Indicates the Thermal Targeting function is Active
6. Economy Target – Illuminates when the boiler reaches the Thermal Target.

Caleffi Circulator Relay



Caleffi DIP Switch Settings



The ZSR series of control is programmed by positioning five dip switches for the following operations.

Master / Slave: allows for unlimited expansion to additional ZVR or ZSR relays. Only one Master.


Priority ON / OFF: When priority switch is ON, upon demand to TSTAT 1 , ZONE 1 will operate as priority and all other zones are temporarily switched off (with 1 hour time-out). When priority is OFF, any zones that were active when ZONE 1 was switched on will remain on.

Remote Enable ON / OFF: When remote enable mode is ON, the board will hold off all zones waiting for an external 24 - 120 VAC voltage from the boiler.

Exercise ON / OFF: When exercise mode is ON, each circulator is switched on for 30 seconds following 72 hours of inactivity.

Post Purge Zone #1 ON / OFF: When post purge is ON, Zone 1 pump continues operating for 2 minutes after the priority zone is switched OFF.

Caleffi Boiler Connections




XX = Dry contact rated up to 120 VAC, 2 Amps, which is typically connected to TT on boiler control, closes when any zone calls including priority.

ZONE 1 E/S = Dry contact rated up to 120 VAC, 2 Amps, will close with any call to ZONE 1. Zone 1 can be enabled as a priority zone, typically used for heating domestic hot water. The ZONE 1 E/S can be used to close a DHW contact on boiler controls equipped with these features.


AUX = Dry contact, rated up to 120 VAC, 2 Amps, close when any zone calls and can be used as signal to a variable speed self regulated pump or other controls.

Caleffi Communication Connections



Connect terminals to matching terminal of slave boards D to D, P to P, Ground to Ground. Use 18 gauge thermostat wire and it should be shielded if located in close proximity to high voltage wiring.

Caleffi Input Power




L = Line (hot leg) of 120 VAC supply

N = Neutral of 120 VAC

⏏ = Ground

Note: when connecting 2 or more Z-one controls, all controls must be powered by the same 120 VAC circuit.

Caleffi Zone Pump Outputs




Zone pumps run when corresponding thermostat initiates a demand.

GROUND = Connect the ground from the pump to the ground terminal.

PRIORITY PUMP = Runs when zone #1 calls. Can be programmed to be the priority zone. L = Line (hot leg) of 120 VAC to power the pump, N = Neutral leg of 120 VAC to power the pump.

Remote Enable allows for input of 24-120 VAC from a boiler to allow the zone pumps to operate. When power is removed from Remote Enable, zone pumps will not be allowed to operate. This is useful during warm weather shut down to stop zone pumps from running or if your boiler controls are used to handle priority (DHW) demand and need the zone pumps to be off during the priority demand. Even with power removed from Remote Enable, the ZSR board stays powered to supply power to the thermostats.

Caleffi Primary Pump Output



Primary pump runs when any zone pump runs. Its status during priority (on/off) can be programmed using the jumper pins.

L = Line (hot leg) of 120 VAC to power the pump

N = Neutral leg of 120 VAC to power the pump

Status During Priority ON / OFF: If priority is enabled and the jumper is placed on the ON pins, the primary pump will continue to operate during ZONE 1 demand. When jumper is placed on OFF pins, the primary pump will be OFF during ZONE 1 demand

Electrical Wiring

Danger Electrical Wiring Must Conform to The National Electrical Code, ANSI/NFPA and Local Codes.

The boiler must be electrically grounded and on a separate fused disconnect switch.


Electrical shock is hazardous. Turn off all power supplies before starting to make any wiring connections or repairs.

Refer to wiring diagrams in this manual for electrical connections. The boiler should be connected to a separate, electrical supply circuit with a minimum 15 amp fused rating. Use No. 14 AWG wires rated for at least 90° C. Install a separate fused disconnect or safety switch near the boiler so all power can be shut off for servicing.

Caution: Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.

1. The 26" long burner harness supplied is for the Riello Burner. When using with a Beckett, burner harness length needs to be reduced to approximately 9" by removing the 90° connector and cutting only the BX to length. Reinstall the 90° connector. When properly installed the burner swing door should not be able to open beyond a safe distance without separating the Molex plug connection.
2. Wire the incoming power to the Energy Manager Pro 6000C as indicated in the wiring diagrams, providing overload and disconnect means as required by code.
3. The Plug n' Go Plus by PurePro is the most complete indirect water heater package available. It takes installation to a new level of simplicity with all accessories factory installed and ready to run. The tank is pre-piped and prewired with a white 6-pin connector which plugs directly into the white 6-pin connector located in the back of the Energy Manager Pro 6000C marked for the Plug n' Go. Prioritization of the domestic water is accomplished by selecting the appropriate dip switch on the ZSR106 control module.
4. Turn on power to the Energy Manager Pro 6000C and turn the power switch on the side to the 'On' position. Check for proper voltage on input terminals "L" and "N" before attaching output devices. **FAILURE TO CHECK FOR PROPER VOLTAGE COULD RESULT IN SYSTEM COMPONENT FAILURES.**
5. Install digital non power stealing thermostats to the Caleffi ZSR106 zone board as shown in the wiring diagrams.
6. Install the circulators to the system zone board as shown in the wiring diagrams.
7. 24VAC 40VA auxiliary power is available on the "VR" and "VC" terminals to power any ancillary equipment.

Field Connection - Circulators Using Customer Supplied Indirect Circulator



Optional Plug'n Go Water Heaters

The optional Plug'n Go Plus indirect water heaters are designed to work specifically with the Energy Manager Pro 6000C. These prewired indirect water heaters are equipped with a 6-pin Molex connector which plugs directly into the Energy Manager Pro 6000C, eliminating the need for any additional wiring.

System Checkout

1. Recheck all wiring connections.
2. Restore power to the Energy Manager Pro 6000C and turn the Power Switch to the 'On' position.
3. Adjust the HydroStat high limit set point temperature to a minimum of 150°F.

Control Circuit Safety Checks

Check the safety controls on the boiler after completing the oil burner adjustments. A safety control check for satisfactory performance must be performed.

1. High limit control - With the burner running, reduce the high limit setting until the burner shuts off. Return the high limit to its original setting.
2. With the oil burner running, verify proper operation of the Low Water Cut Off. Refer to the instructions provided by Hydrolevel for testing of the Low Water Cut Off. The oil burner should shut off when the Low Water Cut Off is functioning properly.
3. To check the primary control and flame sensor, shut off oil supply with hand valve while burner is running. Fifteen seconds after flameout the safety switch locks out, ignition stops and the oil valve should close. To restart, open oil supply valve and reset safety switch.

Boiler System Installation and Service Check List

Boiler Model: _____ Serial No.: _____

Energy Manager Pro 6000C Serial No.: _____

Installation Date: _____

Installer Name: _____ Phone No.: _____

Boiler Installation

- Boiler level and in solid contact with floor?
- Boiler and burner wired per wiring diagram and National Electric Code? 120VAC wiring
Type _____ Size _____ AWG
- Burner sealed to boiler? Mounting nuts tight?
- Space is large enough to provide required clearances?
- NFPA 31 Installation of Oil Burning Equipment followed?
- Local, state and national codes, laws, regulations and ordinances followed?

Vent System

- Existing chimney and vent system inspected to NFPA 211 and in good condition?
- New vent pipe installed and properly sealed?
- Vent size checked against boiler manual and codes?

Burner Operation

- Burner Model: _____ Nozzle: _____ GPH _____ Deg. _____ Type _____
- Burner Pump Pressure: _____
- Fuel filter and fuel lines installed and inspected as per burner manual?
- Air bled from oil piping? Piping checked for leaks?
- Burner started, adjusted and tested per burner manual?

Boiler Operation

- Thermostat heat anticipator set per burner manual instructions?
- Limit control tested for proper operation?
- Low Water Cut Off tested?
- Boiler observed going through several operational cycles for proper operation?

Post Installation

- Reviewed owners' information in this manual with owner or maintenance personnel and instructed to keep for future reference?
- Properly filled in and returned warranty registration card to Boyertown Furnace Co. Inserted burner manual instructions with furnace manual for future use

Energy Manager Pro 6000C Boiler Control

5 Year Limited Warranty

Boyertown Furnace warrants that the **components factory installed and wired** in the Energy Manager Pro 6000C Boiler Control are free from defects in material and workmanship under normal usage for a period of five (5) years from the date of original installation.

Components replaced during this warranty period which are defective in material or workmanship will carry a warranty equal to the unexpired portion of the original component warranty or one year from the date of replacement whichever is greater. **Components in the EM Pro 6000C Control package that are believed to be defective must be removed from the EM Pro 6000C casing before being shipped to Boyertown Furnace.** Boyertown Furnace at its discretion will fix or replace components.

If Boyertown Furnace determines that the returned components and/ or parts are defective and that this warranty applies, Boyertown Furnace will furnish the replacement component to an authorized dealer who in turn will forward the components to the heating contractor.

Boyertown Furnace is not responsible for any labor cost for removal and replacement of equipment. Please contact your local F W Webb location for verification of warranty. This warranty does not extend to any equipment subjected to misuse, neglect, accident or improper installation or normal wear and tear.

Upon the request of Boyertown Furnace it shall be the obligation of the purchaser to ship prepaid to Boyertown the **defective part only** for inspection or repair. The alleged defective components must be returned through the proper trade channels in accordance with Boyertown Furnace procedure in force for handling goods returned for the purpose of inspection to determine cause of failure.

This warranty is applicable only to defect in material and workmanship of the components in the EM Pro6000C and shall not cover failure of the EM Pro 6000C or any of its component parts due to any other reason including but not limited to (1) fire, (2) floods, (3) electrical failure, (4) acts of God, (5) and negligent or improper installation.

IMPLIED WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND MERCHANTABILITY SHALL BE LIMITED TO THE DURATION OF THE EXPRESS WARRANTY SET FORTH ABOVE. WITH EXCEPTION OF ANY WARRANTIES IMPLIED BY STATE LAW, AS HEREBY LIMITED, THE FOREGOING EXPRESS WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, GUARANTEES, AGREEMENTS AND SIMILAR AGREEMENTS OF BOYERTOWN FURNACE WITH RESPECT TO THE REPAIR OBLIGATIONS OF BOYERTOWN FURNACE WITH RESPECT TO THE REPAIR OR REPLACEMENT OF THE ENERGY MANAGER PLUS II. BOYERTOWN FURNACE EXPRESSLY DISCLAIMS AND EXCLUDES ANY LIABILITY FOR CONSEQUENTIAL, INCIDENTAL, INDIRECT, PUNITIVE OR SPECIAL DAMAGES OF ANY KIND FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING, WITHOUT LIMITATION, INJURY OR DAMAGE TO PERSONS OR PROPERTY OR DAMAGES FOR LOSS OF USE, INCONVENIENCE OR LOSS OF TIME, BOYERTOWN FURNACE NEITHER ASSUMES NOR AURTHORIZES ANY OTHER PERSON TO ASSUME FOR BOYERTOWN FURNACE ANY LIABILITY OTHER THAN THE LIMITED LIABILITY SET FORTH HEREIN.

In order to assure prompt warranty service, the owner is requested to register the product online. Product registration may be completed online @ www.boyertownfurnace.com. If the product is not registered the customer will be asked to provide a copy of the original invoice or other proof of purchase, original installation date, and the serial number of the EMPII.

Boyertown Furnace Company
156 Holly Road
Boyertown, Pa. 19512

 -----Cut and Return This Form or Register Online at www.boyertownfurnace.com-----

Warranty Registration
Boyertown Furnace Co.
P.O. Box 100
Boyertown, PA 19512

Date Installed: _____

Model Number: _____

Serial Number: _____

Name of Purchaser: _____

Purchaser's Address: _____

Dealer's Name: _____

Dealer's Address: _____