




Filler & Scribe Guide



36" Lengths Filler & Scribe

Filler:	Scribe:
34" thick	1⁄4" thick
6" wide	3/4" wide
36" long	36" long





Cut Filler or Scribe to length and secure in place with adhesive or fasteners of your choice.

Fillers are commonly ripped (cut) to the width desired by installer. Note that the space to fill may be wider or narrower at the top than at the bottom and requires a cut to fit.